



Input List 2004

Notes:	
1 st Choice/2 nd Choice/3 rd Choice	
**= No Stand	
Short= Short Round Base Boom Stand	
Boom= Tall Round Base Boom Stand	
Straight= Straight Round Base Stand	
ROAD MGR: Mariano Longo	
SND ENG : TBD	
IN:	BAND IN:
SND CK	REH:
SHOW	OUT

MONITOR MIXES	
1 Gary Puckett	
2 Wedges	
2 Keys	
1 Wedge	
3 Bass	
2 Wedges	
4 Drum	
2 Wedges	
5 Side Fill SR	
1 Cabinet	
6 Side Fill SL	
1 Cabinet	
7 Conductor	
1 Wedge	
8 Saxes	
1-Wedge	
9 Trumpets/Bones	
1 Wedge	
10 Spare Mix if Needed per Orchestra	
1 Wedge	
11 Spare Mix if Needed per Orchestra	
1 Wedge	
12 Spare Mix if Needed per Orchestra	
1 Wedge	

SUB	CHANNEL	MIC/DI	STAND	
	1 Kick	Beta 52/91/MD421	**/Short	
	2 Snare	SM57	Short	
	3 Hat	SM81	Short	
	4 Rack	EV468/SM98	Short/**	
	5 Floor Tom #1	EV468/SM98	Short/**	
	6 Floor Tom #2	EV468/SM98	Short/**	
	7 O. H. Left	SM81	Boom	
	8 O. H. Right	SM81	Boom	
	9 OPEN			
	10 OPEN			
	11 Bass	DI	**	
	12 Guitar Left	SM57	Short	
	13 Guitar Right	SM57	Short	
	14 Kurzweil PC-88 Left	DI	**	
	15 Kurzweil PC-88 Right	DI	**	
	16 Roland XP-80 Right	DI	**	
	17 Roland XP-80 Right	DI	**	
	18 Vocal Keys	SM58	Boom	
	19 Vocal Gary Puckett	RF SM58/87	Boom	
	20 Vocal Bass	SM58	Boom	
	21 Vocal Drums	SM58	Boom	
	22 Vocal Spare	SM58	**	
	23			
	24 1 st Violins (Principle)	Isomax/KSM32/EV468	**/Short	
	25 1 st Violins	2-Isomax/KSM32/EV468 y'd	**/2-Short	
	26 2 nd Violins (Principle)	Isomax/KSM32/EV468	**/Short	
	27 2 nd Violins	2-Isomax/KSM32/EV468 y'd	**/2-Short	
	28 Violas (Principle)	Isomax/KSM32/EV468	**/Short	
	29 Violas	2-Isomax/KSM32/EV468 y'd	**/2-Short	
	30 Cello's (Principle)	Isomax/ GLM/KSM32	**/Short	
	31 Cello's	2-Isomax/ GLM/KSM32 y'd	**/2-Short	
	32 Flute/Piccolo	EV468/SM57/D2	Short	
	33 Oboe/English Horn	EV468/SM57/D2	Short	
	34 Clarinet	EV468/SM57/D2	Short	
	35 Baritone Sax	MD421/EV468/SM57	Short	
	36 Tenor Sax	EV468/SM57/D2	Short	
	37 Alto Sax	EV468/SM57/D2	Short	
	38 Trumpets	EV468/SM57/D2	Straight	
	39 Trombones	EV468/SM57/D2	Straight	
	40 French Horns	2-SM57's y-d	2-Short	
	41 Percussion	SM81	Boom	
	42 Percussion	SM81	Boom	
	43 Percussion	SM81	Boom	
	44 Conductor/MC	SM58	Straight	
	45			
	46			
	47 CD Left			
	48 CD Right			